



## USB WriteBlocker™

### Quick Start Guide

#### Using USB WriteBlocker

- Step 1. Attach the target drive/device to the “Drive” side of USB WriteBlocker.
- Step 2. Attach the USB extension cable to the “Host” side of USB WriteBlocker.
- Step 3. Attach the USB extension cable to the computer.
- Step 4. Watch for the drive to mount to the computer. If it does not mount, press the “Remount” button on USB WriteBlocker.
- Step 5. Use the status LED as indication of the drive/device activity.



Thank you for purchasing a WiebeTech product.

A complete user's manual and a free software application to access CID/VID information of the Device under Capture is available at:

<http://www.wiebetech.com/usbwb>