



Protecting Your Digital Assets



1 PACKAGE CONTENTS

The following list contains the items that are included in the complete configuration for this device. Please contact CRU if any items are missing or damaged:

Item	Quantity
Rhino Jr RJ24S	1
SATA data cable	4
Triangular key	4
Computer case mounting screws	8
Drive mounting screws	16
User Guide	1

2 HARDWARE SETUP

2.1 RJ24S INSTALLATION

- Slide the Rhino Jr RJ24S removable drive enclosure into an open 5.25" Floppy Drive bay in your computer.
- Secure the RJ24S to the chassis with the mounting screws provided.
- Attach a Molex power connector from your computer's power supply to the rear of your computer.

NOTE Use one power connector. If the power is not enough or is unstable, please use two power connectors.

- Attach the included SATA data cables to the connector on the rear of the RJ24S and attach the other ends to the appropriate SATA ports on the computer's motherboard or SAS/SATA host card.



CRU® Rhino® Jr RJ24S
2.5" Quad Drive Enclosure

User Guide



2.2 DRIVE INSTALLATION

- If the drive bay is locked, use the included triangular key to unlock it by rotating the key 90 degrees clockwise.
- Pull the bay door handle toward you to open it and slide the tray out.
- Screw your drive onto the bottom of the tray using four of the provided screws.
- Slide the drive tray assembly into the drive bay and apply firm pressure until the bay door closes. The drive will spin up automatically.
- You can optionally lock the drive bay using the included triangular key.

Your RJ24S is now ready to use! If the drive is already formatted, it can be used right away. If the drive is brand new, or its format is not compatible with your computer, it will need to be formatted before being used.

STOP! Formatting a drive **will** result in data loss, so be sure to back up your data before beginning this operation.

3 EJECTING DRIVES FROM THE RJ24S

- If the drive bay is locked, insert the triangular key into the keylock and rotate it 90 degrees clockwise.
- Pull the bay door handle toward you to open it and slide the tray out.



4 LED BEHAVIOR

Color	State	Description
Blue	Solid	The drive inside the bay is powered on.
	Blinking	The drive inside the bay is being accessed by your computer.
Red/Blue	Alternating Blinking	A fan on the rear of the enclosure has failed.

5 TECHNICAL SPECIFICATIONS

Product Models	Rhino Jr RJ24S
Interface Types & Speeds	SAS/SATA: up to 6 Gbps
Supported Drive Types	2.5-inch SAS or SATA drives up to 15mm in height
Data Connectors	Four (4) SATA connectors
Supported Operating Systems	Windows 10, 8, 7, and Vista Windows Server 2012 and 2008 product families OS X/macOS 10.10 "Yosemite" or newer Linux distributions that support the connection type used
Torque	2.5-inch drives, M3 screws: 4 inch-pounds max.
Compliance	EMI Standard: FCC Part 15 Class B EMC Standard: EN55022, EN55024 CE
Product Weight	1.63 pounds (0.739 kg)
Product Dimensions	5.95" L x 5.82" W x 1.65" H (151mm L x 148mm W x 42mm H)
Technical Support	Your investment in CRU products is backed up by our free technical support for the lifetime of the product. Contact us through our website, cru-inc.com/support or call us at 1-800-260-9800 or +1-360-816-1800.



©2016 CRU Acquisition Group LLC. ALL RIGHTS RESERVED. CRU® and Rhino® are trademarks of CRU Acquisition Group, LLC and are protected by trademark law.

Product Warranty

CRU warrants this product to be free of significant defects in material and workmanship for a period of three years from the original date of purchase. CRU's warranty is nontransferable and is limited to the original purchaser.

Limitation of Liability

The warranties set forth in this agreement replace all other warranties. CRU expressly disclaims all other warranties, including but not limited to, the implied warranties of merchantability and fitness for a particular purpose and non-infringement of third-party rights with respect to the documentation and hardware. No CRU dealer, agent, or employee is authorized to make any modification, extension, or addition to this warranty. In no event will CRU or its suppliers be liable for any costs of procurement of substitute products or services, lost profits, loss of information or data, computer malfunction, or any other special, indirect, consequential, or incidental damages arising in any way out of the sale of, use of, or inability to use any CRU product or service, even if CRU has been advised of the possibility of such damages. In no case shall CRU's liability exceed the actual money paid for the products at issue. CRU reserves the right to make modifications and additions to this product without notice or taking on additional liability.

FCC Compliance Statement: "This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation."

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a home or commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications.

In the event that you experience Radio Frequency Interference, you should take the following steps to resolve the problem:

- 1) Ensure that the case of your attached drive is grounded.
- 2) Use a data cable with RFI reducing ferrites on each end.
- 3) Use a power supply with an RFI reducing ferrite approximately 5 inches from the DC plug.
- 4) Reorient or relocate the receiving antenna.

Part Number: A9-110-0010-1 Rev. 1.0
1000 SE Tech Center Dr. Suite 160, Vancouver, WA 98683

